



415 Pembroke Circle, Alpharetta, GA 30004

770-693-2613

Installation Guidelines – Exposed Pipe Showers (Bath-Outdoor)

Packaging – check your product for all parts.

NOTE: Installation is the same for all showers. Those with Hand showers have one additional step



Outdoor shower Installation (60003, 60009, 60014, 60018, 60021, 60022, 60024, 60025)

Indoor Showers (50009, 50018, 50020, 50021, 50022)

Step one - Verify supply lines should be 6 inches (+/- 1/8 inch) apart and a minimum of 24 inches from the ground. Indoor shower installation may vary due to code

Step two – Attach female threaded adaptor to the supply line (not included). Thread size (1/2 - 12)

Step Three - Thread adaptor onto the supply lines (smallest side)



Please make sure the S adaptors are straight

Step four – On the back of the valve body, locate nuts and position adaptor from the supply line. Start threading by hand and tighten using a spanner wrench. (Spacers are provided)



If the spread is larger than 6 inches, move the S adaptors to fit.

Step five – Attach riser to the valve body



Use Teflon tape or silicone on threads.

Use Teflon tape on threads

Step six – Locate wall bracket for riser. Mark your location on the wall and attach wall bracket. Secure escutcheon. Insert mounting pipe into mounting bracket and clip into place



Step Seven – Attach hose (60014, 60018) to the bottom of the valve body, and hand shower. Hanger is already located on the riser.



Step Eight – thread shower head to the riser.



Use Teflon tape on threads and hand tighten snug with spanner wrench.

**TURN ON SUPPLY LINES AND TEST YOUR CONNECTIONS FOR
LEAKS.....**

Enjoy your new outdoor shower!

